LOCATION	QUAN	ITEM	PART NUMBER	DESCRIPTIN
Adapter to transmission	5	Bolt	384960-S100	(BB-429-UN)-bolt (retainer to trans. case)-7/16"-14 x 1 1/4"
	5	Lockwasher	34793-S2	(X-67-A)-lockwasher-7/16"
Adapter to transfer case	6	Bolt	376058-S	(BB-157-A)-bolt-(retainer to transfer case)-3/8"-16 x 1 1/2"
	6	Lockwasher	34807-S8	(X-66)-lockwasher-3/8"
Rear output shaft bearing retainer	4	Bolt	356685-S	bolt (retainer to transfer case)-3/8"-16 x 7/8"
	5	Lockwasher	34807-S	(X-66)-lockwasher-3/8"
	1	Bolt	376058-S	(BB-157-A)-bolt-(retainer to transfer case)-3/8"-16 x 1 1/2"
Front output shaft front cover	4	Bolt	354135-S7-8	(BB-155-A)-bolt (housing to case) 3/8"-16 x 1 1/8"
	4	Lockwasher	34807-S	(X-66)-lockwasher-3/8"
Front output shaft rear cover	4	Bolt	356685-S	bolt (retainer to transfer case)-3/8"-16 x 7/8"
	4	Lockwasher	34807-S	(X-66)-lockwasher-3/8"
Intermediate gear shaft lock plate	1	Bolt	382985-S2	(BB-427-Z)-bolt (plate to transfer case)-5/16"-18 x 5/8"
Typo on drawing, 34806 is correct	1	Lockwasher	34806-S7	(X-65)-lockwasher-5/16"
Side cover plate	10	Bolt	382985-S	(BB-427-Z)-bolt (cover to case)-5/16"-18 x 5/8"
Typo on drawing, 34806 is correct	10	Lockwasher	34806-S7	(X-65)-lockwasher-5/16"
Shift rod spring retainers	3	Hex head set screw	352015-S	(UU-2)-set screw (retain spring and ball in case)-7/16"-20 x 5/16"